


Multimedia system, Rear left treble loudspeaker, Rear right treble loudspeaker, Rear left mid-range and bass loudspeaker, Rear right mid-range and bass loudspeaker

- RX7 Multimedia system
- R14 Rear left treble loudspeaker
- R16 Rear right treble loudspeaker
- R159 Rear left mid-range and bass loudspeaker
- R160 Rear right mid-range and bass loudspeaker
- T8c 8-pin connector
- V17 Connection (positive, rear left loudspeaker), in speaker wiring harness
- V18 Connection (negative, rear left loudspeaker), in speaker wiring harness
- V19 Connection (positive, rear right loudspeaker), in speaker wiring harness
- V20 Connection (negative, rear right loudspeaker), in speaker wiring harness

* For models with 3 doors



Pro cted by copyright. Copying for whatever commercial purposes, in part or in whole, is not permitted unless authorised by SEAT S.A. SEAT S.A. does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by SEAT S.A.

ws = white
sw = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = purple
vi = purple
ge = yellow
or = orange
rs = pink